



EUROPEAN UTILITY REQUIREMENTS FOR LWR NUCLEAR POWER PLANTS

VOLUME 2

GENERIC AND NUCLEAR ISLAND REQUIREMENTS

CHAPTER 5

CODES AND STANDARDS

Revision E
December, 2016

*The EUR promoters assume no liability
for any consequences of the use of any part of
the EUR document by a third party.*

List and status of the sections of the Chapter 2.5 Revision E of December, 2016

CODES AND STANDARDS

<i>Section Number</i>	<i>Section Title</i>	<i>Last change</i>
2.5 1	INTRODUCTION	E-01
2.5 2	APPLICABILITY CRITERIA	E-01
2.5 2.1	Level I - legislation	E-01
2.5 2.2	Level II - European Utility Requirements - EUR	E-01
2.5 2.3	Level III - nuclear documents, process oriented	E-01
2.5 2.4	Level IV - nuclear documents, component oriented	E-01
2.5 2.5	Level V - conventional Codes and Standards	E-01
2.5 3	IDENTIFICATION OF RULES	E-01
2.5 3.1	List of acronyms	E-01
2.5 4	LEVEL III AND IV RULES APPLICABLE TO STRUCTURES SYSTEMS AND COMPONENTS SAFETY CLASSES 1 AND 2	E-01
2.5 4.1	Table 1 - examples of level III and IV Rules for Safety Classes 1 and 2 items	E-01
2.5 5	LEVEL III AND IV RULES APPLICABLE TO STRUCTURES SYSTEMS AND COMPONENTS SAFETY CLASS 3	E-01
2.5 5.1	Table 2 - examples of level III and IV Rules for Safety Class 3 items	E-01
2.5 6	LEVEL III AND IV RULES APPLICABLE TO STRUCTURES SYSTEMS AND COMPONENTS NON SAFETY CLASS	E-01
2.5 6.1	Table 3 - examples of level III and IV Rules for Non Safety Class items	E-01
2.5 7	FIGURE 1 - LEVELS OF RULES	E-01

